SRCV4


VCAL
AVDD
ISET
VRSET
PB127
NCAS
AGND
RB127
WB127
AREF
IQUI
VTH
DGND
DVDD
D0MODE
USESEU
ISLOPE
BNBR
PRIOUT
PRIIN
SVDD
SGND
PRIN+
PRIN−
PRIOUT1−
(unused)