



Granule Timing Module

Contact People:

[Leo Paffrath](#)

[Sy Rankowitz](#)

[John Schmidt](#)

[Joe Mead](#)

Revision 2.2

Last Update: 4/4/97

1.0 Introduction

This document describes the Phenix Granule Timing Module. The Granule Timing Module, which resides on a single width 9U VME-P board, provides distribution of the timing information to the front end modules (FEM) for the Phenix Detector. The timing module performs three primary functions. First, it is a mode bit scheduler, which outputs predetermined mode commands on a clock by clock basis to the FEM's. Second, it provides readout enable strobes to the FEM's, and monitors the number of level-1-accepts generated by the level1 system. Third, it provides low jitter distribution and generation of timing signals, namely the Beam Clock, Beam ClockX4 (generated on board via PLL), and LVL-1 Accept. The module is interfaced via the VME bus. The block diagram showing all inputs and outputs from the module is shown in figure 1.




figure 1. Granule Timing Module Block Diagram

2.0 Board Level Overview

2.1 VME Interface

The VME interface conforms to the ANSI/VITA 1-1994 VME64 Specification, and provides additions from the VITA 1.1-199x VME64 Extensions Draft Standard, Draft 1.4 It is a slave only device.. The board supports A32 Addressing for all operations, and D32,D16,D08(EO) data transfers. The boards base address is determined from the geographical address pins GA4-GA0 on the VME backplane.




figure 2. Timing Module VME memory map

2.1 Phenix Specific Registers

The first 256 memory locations of the board are reserved for Phenix System Level Registers. Only the first four bytes have been defined, although no values have been assigned as yet, the remaining memory space is reserved for future use.

BOARD ID: base+0h		PHENIX Board ID	
Field	Bits	R/W	Function
TYPE	31..0	R	Board Type

BOARD NUM	23..16	R	Board Number
TRANS NUM	15..8	R	Transition Modules Attached
RSVD	7..0	R	Reserved

table 1. Phenix Defined Registers

3.0 Timing Subsystem

The timing subsystem performs three primary functions. First, it is a mode bit scheduler, which outputs predetermined mode commands on a clock by clock basis to the FEM's. Second, it provides readout enable strobes to the FEM's, and monitors the number of level-1-accepts generated by the level1 system. Third, it provides low jitter distribution and generation of timing signals, namely the Beam Clock, Beam ClockX4 (generated on board via PLL), and LVL-1 Accept. Figure 3 below shows the block diagram. Each of the following functions will be discussed in detail next.




figure 3. Block Diagram of Timing Subsystem

3.1 Mode Bit Scheduler

The Timing Interface provides an eight bit encoded command word (mode bits) for each beam crossing to all FEM's. *Mode commands* are defined as the encoded value of the eight mode bits. *Mode commands* are grouped together, into *Mode Command groups* where a group represents a single fiducial of the RHIC accelerator. At the current time there are 120 such beam crossings per fiducial, therefore a *Mode Command group* consists of 120 *Mode Commands*. With the use of an SRAM

as the storage devices for *Mode Commands* and a separate SRAM containing a list of pointers (*Scheduler Commands*) to the beginning of any *Mode Command Group*, mode bits can be defined for unlimited number of cycles (with repetition).

3.11 Scheduler Commands

Scheduler commands are 32 bit instructions loaded in the *Scheduler Memory* SRAM, which has a depth of 32K. The *scheduler commands* are to be loaded in the order of planned execution. The format for the *scheduler command* is shown in table 2. Bit 31 is the retransmit bit. A logic 1 in this bit will reset the Scheduler, thereby looping back to the first *scheduler command*. Using this loopback feature mode commands may be issued to the FEM's for an unlimited time. Bits 30-8 define the Scheduler Command repeat bits. The binary value assigned here represents the number of times to cycle through the current Mode Command Group. Bits 7-0 define which of the 256 unique Mode Command Groups to perform. The binary value assigned here is a pointer into the Command SRAM to a unique Mode Command Group. The address of the currently executing Scheduler command may be read from the Timing Control and Status Registers *CYCLE_PTR*.

Field	Bits	R/W	Function
RETRAN	31	R/W	Retransmit
CYCRPT	30..8	R/W	Scheduler Command Repeat Value
CYCCMD	7..0	R/W	Mode Bit Group Number

Table 2. Scheduler Command Bit Definitions

3.12 Mode Commands

Mode Commands are 32 bit instructions loaded in the *Command Memory* SRAM, which has a depth of 32K. The first byte, (D7-D0) loaded into this SRAM are the mode bits which are destined to the FEM's via the GLINK. The next byte, (D15-D8) are for Local Level 1 use and the upper byte (D23-D16) is for the use of the programmable pulse generator. The most significant byte, (D31-D24) is reserved for future use. There is room for storing 256 unique Mode Command Groups (each mode command group consists of 120, 32 bit, mode commands). The first mode command of each of the mode command groups must be aligned at 512 byte offsets, as shown below in figure 4.




figure 4. Mode Command SRAM

3.13 Mode Bit Scheduler Operation

A block diagram of the operation of the mode bit scheduler is shown below in figure 5. A quick overview of the procedure for loading and running the scheduler is described. Mode bits are loaded into the Command SRAM in groupings of 120, which is the number of crossings per fiducial. Each new grouping starts on a 512 byte boundary. Then the scheduling commands are loaded into the scheduler SRAM with the format described in table 3. Up to 32 thousand scheduling commands may be loaded. When the mode bit scheduler starts, by a global start signal, the control logic fetches the first command from the scheduler SRAM and the various fields flow through to the three blocks labeled Cycle Command Base Addr Latch, Repeat Value Counter, and Control Logic. The lower eight bits (CYCCMD) form the upper bits on the Command SRAM, it points to the Base Address of a unique mode bit group. A cycle counter then begins which counts from 0 to 119 on each Beamclk, which provides the lower bits on the Command SRAM. This counter then runs until the Cycle Repeat Field (CYCRPT) has been decremented to zero. The Control logic block recognizes this and then fetches the next command from the scheduler SRAM and the process repeats itself. If the retransmit bit is set (RETRAN), then the next cycle command address will be the first memory location of the scheduler SRAM.




figure 5. Mode Bit Scheduler Operation

3.14 Editing Single and Cycle Commands

To modify and/or read any of the scheduler commands (Scheduler Memory) and/or mode commands (Command Memory) the module must be in a stopped mode. Attempting to change these values while the module is in run mode will have no effect and attempting to read these values while the module is in run mode will result in undefined data. The control and status registers are always available to the VME bus.

The procedure for stopping the module is to set the *STOP_LOCAL* bit of the Timing CSR and then poll on the *RUN* bit to verify that the module has stopped. (The module may not stop immediately, depending on the value of the bits *STOP_EOSF* and *STOP_EOCC* of the Timing CSR) Once the module has been placed in the stopped mode both the scheduler commands and the mode commands may be read and/or modified.

After any modifications have been performed the module may then be restarted either locally or globally by the methods described in the next section

3.15 Global/Local Start/Stop Procedures

The timing module is started and stopped through the global control inputs: global Start and global Stop. Two control bits, *START_ENABLE* and *STOP_ENABLE*, also exist which enable the modules to accept and process these Global signals. These control bits allow groups of timing modules to be synchronously started and stopped. Upon receiving a global Start pulse and having the control bit *START_ENABLE* asserted, the module enters an arming state where it then awaits a Fiducial Clock pulse, which synchronizes it to a predetermined RHIC accelerator bucket. The next Beam Clock pulse puts the module into a run mode and mode bits are output. This is shown in figure 6.




figure 6. Timing Diagram for starting the module

To globally stop the module the board must receive a global Stop pulse and have the control bit *STOP_ENABLE* asserted. Then depending on the current value of the control bits: *STOP_EOSF* (stop at end of sequence fifo) and *STOP_EOCC* (stop at end of current cycle (see section 4.2 for details on these bits)), the module will stop accordingly.

3.2 LVL1-Accept Handler and Readout Enable Generation

The timing module provides a mechanism for handling the LVL1-Accept pulses generated by the GL1 System and providing readout enable pulses to the FEM's based on these pulses.

3.21 LVL1-Accept Handler

To prevent data overrun in the FEM's or in the DCM's, the rate of LVL1-Accept triggers must be monitored. This is accomplished by tracking the current number of LVL1-Accepts that are queued for readout with a three bit counter *EVT_CNTR*. If this counter reaches a value of 5 then a handshake signal **COUNT5* is asserted and returned to GL1, thereby inhibiting it from generating any more LVL1- Accept pulses. Upon assertion of the **COUNT5* signal, a presettable longtime timer, *LTTIMER*, is started. This timer has a maximum time of about 6.5ms, but may be preset by the user for a shorter duration. When this timer reaches zero, the *EVT_CNTR* should also be at zero. If it is, the signal **COUNT5* is negated, enabling the GL1 system to resume sending LVL1-Accepts. If it is not, then there is a data-flow problem (Most likely the **DCMBUSY* input is asserted) and the error bit *CNTERR* is asserted.

3.22 Readout Enable Generation

With the use of the LVL1-Accept pulses, the Timing Module controls the readout of data from the FEM's to the DCM's with two signals, *ENDAT0* and *ENDAT1*. These two signals are output via the GLINK to the FEM's. In general, when a LVL1-Accept is received the following occurs depending on the current value of *EVT_CNTR* (described in section 3.21):

LVL1-Accept received when *EVT_CNTR* = 1

The LVL1-Accept is passed to the FEMs via the GLINK. Also a 16 bit programmable counter, *FEM_CNVRT_TIME* is started. This timer allows the front end to complete the conversion. The nominal time setting for this counter is 40uS. After this timer has timed out the first data enable (*ENDAT0*) is asserted. The width of this signal is the time required for the even FEMs to transmit their data and is controlled by a 16 bit programmable counter, *ENDAT_TIME*. After this timer has timed out, *ENDAT0* is negated and *ENDAT1* is asserted. The width of *ENDAT1* is the time required for the odd FEMs to transmit their data and is controlled by the same counter, *ENDAT_TIME*. After this timer has timed out, *ENDAT1* is negated and the counter *EVT_CNTR* is decremented. This is shown below in figure 7.




figure 7. Timing Diagram for $EVT_CNTR = 1$

LVL1-Accept received when $EVT_CNTR > 1$

The same as the case $EVT_CNTR = 1$, however the counter, FEM_CNVRT_TIME , will not be started until the beginning of $ENDAT1$ has started. This is shown below in figure 8.




figure 8. Timing Diagram for $EVT_CNTR > 1$

3.23 Data Collection Module Busy

The input signals $*DCMBSY[3:0]$ is provided from the DCMs, and is used to prevent the FEMs from passing more data to the DCMs if they have signalled that they are full, can't unload, etc. This is accomplished in the logic described above by only letting the current data transmission (both $ENDAT1$ and $ENDAT2$) run to completion. No further LV1-Accepts are generated by GL1, and when the DCMs are no longer "busy", the above protocol resumes. The four $*DCMBSY$ signals are internally or'd together to produce the signal $*GRANBSY$ which is passed back to the global level 1 system.

3.3 Clock Generation & Phase Control

3.31 On Board Clock Generation

The BeamClkX4 is generated on board via a programmable skew clock buffer. The Cypress part CY7B991 provides a low jitter output ($<25ps$ RMS) for the BeamClkX4. The part multiplies the BeamClk by a factor of four which directly drives the clock input to the GLINK.

3.31 Phase Delay

The incoming BeamClk signal can be delayed between 10ns - 132ns via on board programmable delay generators. The resolution of this delay is +/- 20ps. There are three registers for controlling the phase delay of the BeamClk Signal. *FINEDLYADJ* controls an MC10E195 programmable delay chip whose typical range is 1.39ns - 3.63ns over 128 steps. *COURSEDLYADJ* controls a DS1020 programmable delay chip whose typical range is 10ns - 48.25ns over 255 steps. Finally, *ROUGHDLYADJ* simply delays the BeamClk signal by delaying it by single 37Mhz periods giving discrete delays of 0,27ns,54ns,and 81ns. By combining these three delay methods a continuous range of delay can be programmed for the BeamClk. See section 3.3 for details on the register values.

3.3 GLINK Interface

All outputs from the Timing Interface will be placed onto a Hewlett Packard HDMP-1012 Transmitter (GLINK). This virtual ribbon cable interface provides a high speed serial path for 20 parallel bits. The bit assignment for the timing signals is shown below in table 3

.

Data Line	Function
D0	Mode Bit 0
D1	Mode Bit 1
D2	Mode Bit 2
D3	Mode Bit 3
D4	Mode Bit 4
D5	Mode Bit 5
D6	Mode Bit 6
D7	Mode Bit 7
D8	Beam Clock (9.4Mhz)
D9	LVL1 Accept
D10	Mode Enable
D11	EnDat0
D12	EnDat1
D13	User Bit 0
D14	User Bit 1
D15	User Bit 2
D16	Reserved
D17	Reserved
D18	Reserved
D19	Reserved

Table 3. GLINK Bit Assignments

The GLINK will be clocked at four times the Beam Clock (BeamClkX4) which has been generated via an on board PLL and will have a maximum jitter of 25ps rms. All other signals will have a frequency no greater than the BeamClk. The BeamClk signal (D8) will always be present and will provide phasing information for the BeamClkX4 signal. The BeamClkX4 should be used as the accurate timing reference, and the BeamClk signal used to indicate the beam crossing (zero to one transition on BeamClk).

The Three User Bits are levels which are mapped directly from VME space. Their encoded value represents various functions for FEM's to perform. Refer to section 3.4 for the definition of these values

3.4 Timing Subsystems Control & Status Registers

The following section provides specific information on programming and controlling the timing subsystem through its control & status registers via the VME interface.

TIMING CSR: base+100h		Mode Bit Scheduler: Control & Status	
Field	Bits	R/W	Function
CYC_RETRAN	0	W	Asserting this bit resets the scheduler SRAM pointer to the first scheduler command. This pointer value may be read from the SCHEDULER_PTR Register.
STOP_EOSF	1	R/W	When this bit is asserted to a logic 1, the cycle commands will stop executing as soon as a scheduler command with the retransmit bit asserted is completed. When at logic zero, the scheduler commands will repeat indefinitely.
STOP_EOCC	2	R/W	When this bit is asserted to a logic 1, the cycle commands will stop executing as soon as the current scheduler command is completed.
START_ENABLE	3	R/W	Asserting this bit high will enable the module to process a Global Start signal. If it is at logic zero, the module will ignore any Global Start signals. Resets to logic zero.
STOP_ENABLE	4	R/W	Asserting this bit high will enable the module to process a Global Stop signal. If it is at logic zero, the module will ignore any Global Stop signals. Resets to logic zero.
RUN	5	R	A logic 1 indicates that the module is currently sending valid mode bit commands. A logic 0 indicates the module is stopped.
WAIT	6	R	A logic 1 indicates that the module has received a global start pulse, and is awaiting a global fiducial clk pulse to enter the run state.

TIMING CSR: base+104h		Mode Bit Scheduler: Cycle Pointer	
Field	Bits	R/W	Function
SCHEDULER_PTR	15..0	R	This value is the memory address of the current cycle command being executed in the Scheduler Memory.

TIMING CSR: base+108h		Mode Bit Scheduler: Command Pointer	
Field	Bits	R/W	Function

COMMAND_PTR	15..0	R	This value is the memory address of the current command being executed in the Command Memory.
-------------	-------	---	---

TIMING CSR: base+10Ch LVL1-Accept & Read Out Enable: Control & Status			
Field	Bits	R/W	Function
COUNT5	0	R	This is the current value of the global output *COUNT5 that goes to GL1 (see section 3.21) 0=COUNT5 negated, 1=COUNT5 asserted
DCMBUSY[3:0]	4..1	R	This is the current value of the global inputs *DCMBUSY that comes from the Data Collection Modules (see section 3.23) 0=DCMBUSY negated, 1=DCMBUSY asserted
GRANBUSY	5	R	This is the grand-or of the four DCMBUSY registers 0=GRANBUSY negated, 1=GRANBUSY asserted
CNTERR	6	R/W	This bit is asserted if the timer, <i>LTTIMER</i> , has timed out and <i>EVT_CNTR</i> is not equal to zero. Indicates a data-flow problem. This bit may be cleared (see section 3.21)

TIMING CSR: base+110h LVL1-Accept & Read Out Enable: Event Counter			
Field	Bits	R/W	Function
EVT_CNTR	2..0	R	Current Number of LVL1-Accepts events currently being processed.

TIMING CSR: base+114h LVL1-Accept & Read Out Enable: LongTime Timer			
Field	Bits	R/W	Function
LTTIMER	15..0	R/W	Preload value of the LongTime Timer (see section 3.21) LTTIMER = Timer Length / 108ns

TIMING CSR: base+118h LVL1-Accept & Read Out Enable: FEM Convert Timer			
Field	Bits	R/W	Function
FEM_CNVRT_TIME	15..0	R/W	Preload value of the FEM Convert Timer (see section 3.21) FEM_CNVRT_TIME = Timer Length / 108ns (initialized to 40us (172h))

TIMING CSR: base+11Ch LVL1-Accept & Read Out Enable: Enable Data Timer			
Field	Bits	R/W	Function
ENDAT_TIME	15..0	R/W	Preload value of the Enable Data Timer (see section 3.21) ENDAT_TIME = Timer Length / 108ns (initialized to 40us (172h))

TIMING CSR: base+120h Clock Generation & Phase Control: Fine Delay Control			
Field	Bits	R/W	Function
FINEDLYADJ	6..0	R/W	Fine Adjust of Phase Delay for the BeamClk. Range is approx 0 to 2ns. Corresponds to the bits on the MC10H195

TIMING CSR: base+124h Clock Generation & Phase Control: Course Delay Control			
Field	Bits	R/W	Function
COURSEDLYADJ	7..0	R/W	Course Adjust of Phase Delay for the BeamClk. Range is approx 0 to 48ns. Corresponds to the bits on the DS1020

TIMING CSR: base+128h Clock Generation & Phase Control: Very Course Delay Control			
Field	Bits	R/W	Function
ROUGHDLADJ	1..0	R/W	Very Course Adjust of Phase Delay for the BeamClk. Uses the 37Mhz clock to delay the beamclk in 27ns step intervals. 00=0ns, 01=27ns, 10=54ns, 11=81ns.

TIMING CSR: base+12Ch GLINK Interface: User Bits			
Field	Bits	R/W	Function
USER_BITS	2..0	R/W	<p>Sets the level of the GLINK bits D13 (Bit 0),D14(Bit 1),D15 (Bit 2) These bits are encoded to represent the following functions:</p> <p>000 : no function 001 : Arcnet Reset 010 : 011 : 100 : 101 :</p>

			110 :
			111 :

TIMING CSR: base+130h GLINK Interface: Reset GLINK Transmitters			
Field	Bits	R/W	Function
GLINKRESET	3..0	R/W	Resets the selected GLINK transmitter. Selected GLINK is encoded into the four bits. A write value of Fh has no effect. When reset of the GLINK reset has completed a value Fh will appear as readback.

TIMING CSR: base+134h Reserved			
Field	Bits	R/W	Function
RSVD	15..0	R/W	This register has been reserved for future use

TIMING CSR: base+138h Reserved			
Field	Bits	R/W	Function
RSVD	15..0	R/W	This register has been reserved for future use

TIMING CSR: base+13Ch Reserved			
Field	Bits	R/W	Function
RSVD	15..0	R/W	This register has been reserved for future use

Please report any problems to [Joe Mead](#)