
Brief Summary Document of Phenix Magnet Dimensions and Parameters

Lawrence Livermore National Laboratory, Livermore, CA 94550.

11th Oct 1996

PHENIX Magnet Subsystem





The PHENIX Magnet Subsystem and Mu ID Steel



- PHENIX has two major magnet subsystems. The Central Magnet (CM) and the Muon Magnet (MM).
- The CM is 9 meters tall and weighs nearly 500 tons.
- The CM single particle resolution is better than 1% between 200 MeV and 1 GeV.
- One pole of the CM serves as the primary absorber of hadrons for the μ arm spectrometer. This required careful optimization of the CM pole face and the neutron and gamma ray absorbers.
- The MM is 10 meters tall and weighs more than 400 tons.
- It has sufficient resolution to resolve the Ψ' from the J/ Ψ and the Y(1S) from the Y(2S+3S).
- The Mu ID steel is part of the muon detector but is integrated with the magnet components for design, structure, and schedule reasons.
- The Mu ID steel is 10 meters tall and weighs more than 600 tons.

The Central Magnet



- The CM is an axial field magnet energized by two pairs of concentric coils, which can be run separately, together, or in opposition.
- It covers a rapidity interval of \pm 0.35 units.
- ∫B•dl = 0.78 Tesla m
- Minimum field in the RICH region to avoid distortion of tracks ⇔ rings.

$$\int B \cdot dl = 100 \text{ gauss - m}$$
 (from 2.4 to 4 meters radius)

 Minimum field at the outer radius of the CM pole where RICH phototubes will be mounted.

 $B_{Tot} \leq 200$ gauss.

Field near the EM Cal ≤ 10 gauss.

JT-C&S-Review: 4

Date: 3/5/94

The Muon Magnet



- The MM uses two solenoidal coils to produce a radial magnetic field. The coils are wound around a tapered piston, the flux propogates out to the lampshade and returns via a 30 cm thick endplate.
- It covers a rapidity interval of 1.1 2.4 units (10° to 37°).
- It has large acceptance in φ angle for low cross-section measurements.
- P_τ kick of ≈ 200 MeV

 $\int B_R \cdot dl = 0.72$ Tesla - m (along a line 15° from the beam axis).


JT-C&S-Review: 5

Date: 3/5/94


The Mu ID Steel




- The Mu ID steel is part of the muon detector but is integrated with the magnet components for design, structure, and schedule reasons.
- The Mu ID steel and Mu ID detectors cause the hadrons to shower and still identify the straight through tracks of the muons.
- The 30 cm thick endplate for the MM is the first layer of the Mu ID absorber.
- The Mu ID absorber consists of 5 more layers of steel: 10 cm, 10 cm, 20 cm, 20 cm, 20 cm each 10 m high and 10 m wide.
- It weighs over 600 tons.
- It fits. The distance between the back of the MM and the far wall is less than 3 meters!








Z Y






PHENIX Mag. Sys. - Configuration Control Dwg.




Central Magnet retracted 1.5 m






PHENIX hall track system (X elevation







PHENIX hall track system (Z elevation)



PHENIX hall track system



