


# Transition from E906 to E1039

Ming Liu


P-25




# E906 vs E1039

- Fixed target dimuon experiments for Drell-Yan and J/Psi productions in p+p and p+A
  - Common Forward Muon Spectrometers
  - Very different target systems

- E906 Targets: “simple”
  - 10~20% of nuclear interaction length, >5cm in diameter
  - LH<sub>2</sub> and LD<sub>2</sub>, ~50cm long, operate at 20K
  - C, Fe and W
- E1039 polarized target:
  - NH<sub>3</sub> operate at 1K, 5T B-field



# From E906 to E1039: To Do List



- Target
- Beam line
- DAQ
- Mechanical
- Cryogenics
- Electrical
- Cooling
- Shielding
- Safety Review

E906 Target Cave


E906 Targets: LH2, LD2, C, Fe, W





# LANL High Density Polarized Proton ( $\text{NH}_3$ ) Target

- Superconducting dipole magnet
  - Temperature  $\sim 1$  K
  - Magnetic Field: 5 Tesla
  - 8cm long  $\text{NH}_3$  target
- Proved capable of handling high luminosity
  - up to  $\sim 10^{35}$  (Hall C)
  - $\sim 10^{34}$  (Hall B)



4-94

7656A1



# Modifications to E906 Setup


## Target and Beam Control

- Some changes @IR
  - New space for operation, target change etc
  - New target stand (a platform )
  - Radiation shielding around the target area
- Target operation and maintenance
  - Service lines, Power, Cryogenic systems
  - NMR system, radiation shielding for electronics, network access
  - Space for target changes etc.
- Beam control
  - A new final focusing quadrupoles (Q3 near target)
  - Beam collimator, target magnet quench protection
  - Beam spot position/direction/size monitors
  - Beam position/direction stability
  - Luminosity monitors, Cerenkov, new telescopes
- Fermilab Engineering and Safety Review

## DAQ and Spectrometers


- Spectrometers
  - New switches to Reverse fields of FMag and KMag for spin asymmetry systematic control
- Triggers
  - A new trigger road map to optimize signal from target
- DAQ
  - Improve DAQ bandwidth
  - Slow control integration into DAQ
- Physics asymmetry systematic controls
  - Precision luminosity

# The Experimental Hall: No Change



# Target Area

- Targets must be rad. shielded
- E906 target cave too small for Pol. Target
- Issues with target and beam dump separation
- Stability of beam on target




Current E906 Target Cave





# Target and Beam Dump Event Separation

move the target upstream:  $Z = -3.5\text{m}$



# Beam on Target: 4-sigma coverage

relative luminosity measurement better than  $2 \times 10^{-4}$


Expected Raw Asymmetry:

$$\sim 1\%/10 \sim 20 = 5 \times 10^{-4}$$


$$\text{Asymetry} = (N^+/\textcolor{red}{R} - N^-)/(N^+/\textcolor{red}{R} + N^-)$$

$\textcolor{red}{R}$  = spin-dependent  
relative luminosity

$$dR < \sim 2 \times 10^{-4}$$



# New Beam Collimator, Focusing Q3 and Target



Target cross section: 18 x 28 mm<sup>2</sup>

Beam cross section:

Need be well contained within  
4 sigma, required by  $dR < 2 \times 10^{-4}$

$\text{sigX} = 18/2/4 = 2.2 \text{ mm}$

$\text{sigY} = 28/2/4 = 3.5 \text{ mm}$


Beam jitter:  $dX=dY \sim 1\text{mm}$

1 sig = 0.68269

2 sig = 0.95450

3 sig = 0.99730

4 sig = 0.99994



E906 beam profile:

SigX = 4.0mm


SigY = 3.0mm

$$f(x, \mu, \sigma) = \frac{1}{\sigma\sqrt{2\pi}} e^{-\frac{(x-\mu)^2}{2\sigma^2}}$$

Beam collimator

Final focusing Q3


120GeV  
beam





Target stick movement: 3.6m to ceiling (tight)

# Polarized Target Operation




## Mechanical issues:

- Need platform to work around for target insert changes, helium refill, Nitrogen refill
- Stand of target magnet
- Crane or Gantry to lift target, max 2000 lb
- New position -350 cm upstream of FMAG
- Pump connections for evaporation cooling
- Pump connection for separator
- Pump connection for main vacuum
- Placement of liquefier system

Beam entry (8' above ground)



# Current E906 Target Cryogenic Service

## Next to the E906 Target Cave



# Root Pump, Microwave and Mechanical Support


- Chiller for microwave
- Where to locate pump?
  - Cave or outside?
- Connect exhaust of magnet to pump





# Conceptual Design of the New Polarized Target Area

- new services and modifications needed to operate the polarized target:
- pumps, cryo, electrical, microwave, NMR





Z = -3.5m


620cm

457 cm

178 cm



Modifications needed



# Shielding and Beam Line Work

## - work in progress

### Radiation Shielding

- Cave/ceiling shielding for new target position
- Electronics around target
  - microwave tube
  - microwave power supply
  - NMR electronics
  - control electronics
  - Magnet power supply, controls
- Calculations for target activation
- Target area radiation monitoring

### Beam line and spectrometer

- Beam size requires additional Quads
- Collimator upstream of target
- Beam position interlock, loss monitors
- Spin-sorted luminosity monitor of beam on target

# More on Service Needs

## Electrical, Water Cooling and Cryogenics

- Pump: 460V
- Fmag and kMAG magnets need field direction switches
- Network close to target
- regular 220 and 110 outlets
- 2.3 lt/min cooling H<sub>2</sub>O
- <sup>4</sup>He and N<sub>2</sub> lines
- Pump lines
- Fermilab Tech support




# Safety and Monitoring

- Radiation monitor and safety interlock
  - Oxygen deficiency monitor
  - Quench lines to outside building
  - Activation analysis for target
- 
- Fermilab Engineering and Safety Reviews of cryogenic, electrical, vacuum, water cooling etc.

# Schedule and Timeline

1. New target area and radiation shielding design and safety review
2. Cryogenics System design and installation
3. Beam line modifications
4. Beam on target monitoring telescopes



# Summary

## Target and Beam Control


- Some changes @IR
  - New space for operation, target change etc
  - New target stand (a platform )
  - Radiation shielding around the target area
- Target operation and maintenance
  - Service lines, Power, Cryogenic systems
  - NMR system, radiation shielding for electronics, network access
  - Space for target changes etc.
- Beam control
  - A new final focusing quadrupoles
  - Beam collimator, target magnet quench protection
  - Beam spot position/direction/size monitors
  - Beam position/direction stability
  - Luminosity monitors, Cerenkov, new telescopes
- Fermilab Engineering and Safety Review

## DAQ and Spectrometers

- Spectrometers
  - New switches to Reverse fields of FMag and KMag for spin asymmetry systematic control
- Triggers
  - A new trigger road map to optimize signal from target
- DAQ
  - Improve DAQ bandwidth
  - Slow control integration into DAQ
- Physics asymmetry systematic controls
  - Precision luminosity



# Current E906 Setup



Drawing: Tom O'Connor  
and K. Bailey

11/3/2014

1/7/15

Ming Liu P-25 LDRD Review